


How To Measure Quickly and Accurately



INSIDE MOUNT (IM) INSTALLATION — For a beautiful framed look

- 1 MEASURE WIDTH**
Measure to the nearest $\frac{1}{8}$ in. between inside surfaces of window frame; at the top, middle, and bottom.
Record the narrowest width of the three.
- 2 MEASURE HEIGHT**
Measure to the nearest $\frac{1}{8}$ in. from inside surface at top of window to top of sill; at the left, middle, and right.
Record the tallest height of the three.
- 3 MEASURE DEPTH**
Measure exact depth of window casing making note of any obstacles i.e. handles, tracks or cranks that could interfere with the blind or shade function.
Use the shortest depth.

HELPFUL HINTS

Always use a metal tape measure as cloth may stretch


Measure your window - not your existing blind or shade

Measure each window separately even if they appear to be identical

Check depth to ensure shade will clear any obstacles and can accommodate headrail if flush mount is desired

If you prefer shade not to touch sill, deduct $\frac{1}{4}$ "

If there is no sill, measure height to point where shade is to reach




OUTSIDE MOUNT (OM) INSTALLATION — For increased light control and privacy

- 1 MEASURE WIDTH**
Measure to the nearest $\frac{1}{8}$ in. between outermost points where shade is to be placed.
Measurement should overlap each side of window frame by at least $1\frac{1}{2}$ in.
- 2 MEASURE HEIGHT**
Measure to the nearest $\frac{1}{8}$ in. from where top of shade will be located to top of sill, or measure to point of shade reach if no sill.

NOTE: Take all measurements to the nearest $\frac{1}{8}$ in. **DO NOT** take any deductions. The factory will make the necessary adjustments to help ensure your window covering operates smoothly.


Visit www.levolor.com/how-to-measure for more measuring information

Window and Measuring Terminology




WINDOW COMPONENTS TERMINOLOGY

- Collectively, the sill and jambs are called the "window casement" or "frame".




INSIDE MOUNT

- Shade fits within window opening.
- Great for windows with beautiful trim.



OUTSIDE MOUNT

- Shade mounts outside window opening.
- Increased light control and privacy.



TWO SHADES ON ONE HEADRAIL

- Provides the clean appearance of a single shade with the ability to operate each shade independently.
- Can be mounted inside or outside.

SIDE MOUNT—NOT ILLUSTRATED

- Used primarily when conventional mounting will not work—for example, in an arched window opening.

How to Measure Two Shades on One Headrail (2-on-1 Headrail)

INSIDE MOUNT (IM) INSTALLATION — For a beautiful framed look

1 MEASURE WIDTH

Total Shade Width — Measure to the nearest $\frac{1}{8}$ in. between inside surfaces of window frame; at the top, middle, and bottom.

Record the narrowest width of the three.

Left Shade Width — Measure the width that you want the left shade to cover.

Order this shade first when placing your order.

Right Shade Width — Measure the width that you want the right shade to cover.

2 MEASURE HEIGHT


Overall Shade Height — Measure to the nearest $\frac{1}{8}$ in. from inside surface at top of window to top of sill; at the left, middle and right.

Record the tallest height of the three.

3 MEASURE DEPTH

Measure exact depth of window casing making note of any obstacles i.e. handles, tracks or cranks that could interfere with the blind or shade function.

Use the shortest depth.



OUTSIDE MOUNT (OM) INSTALLATION — For increased light control and privacy

1 MEASURE WIDTH

Overall Shade Width — Measure to the nearest $\frac{1}{8}$ in. between outermost points where shade is to be placed.

Add an additional 3 in. to 6 in. to total width for maximum privacy.

Left Shade Width — Measure the width that you want the left shade to cover.

Order this shade first when placing your order.

Right Shade Width — Measure the width that you want the right shade to cover.

2 MEASURE HEIGHT

Overall Shade Height — Measure to the nearest $\frac{1}{8}$ in. from where top of shade will be located to top of sill, or measure to point of shade reach if no sill.

2-ON-1 HELPFUL NOTES:

- Available in cordless, corded, and continuous cord loop operating systems.
- Top-Down/Bottom-Up and Day/Night options are available.
- Order the left shade first when placing the order.
- Each shade operates separately.
- There will be a gap between the fabric on the left and right shades to operate independently.
- Desired gap width is selected at time of ordering.
- Minimum gap width is $\frac{1}{4}$ in. maximum gap width is $2\frac{1}{2}$ in.
- For standard Bottom-Up shades, controls will be located on the left side of the left shade and the right side of the right shade.
- The left shade width plus the right shade width plus the inner gap width must equal the overall shade width.
- Fabrics cannot be seamed or overlapped.
- Always use a metal tape measure as cloth may stretch.
- Take all measurements to the nearest $\frac{1}{8}$ in. DO NOT take any deductions.
- The factory will make the necessary adjustments to help ensure your shade operates smoothly.

WIDTH CRITICAL DIMENSIONS

- Smallest panel size for a 2-on-1 is the same as all single shade limits, see critical dimensions page for details.
- Largest panel size for a 2-on-1 is the maximum width minus the minimum panel size. Limitations vary by operating system.

See critical dimensions section on page 7 for additional information.